# Avionics Reference Document

David Knight January 26, 2020



# Contents

| Title   | e Page   | 1  |
|---|--|--|
| Tabl  | e of Contents  | 2  |
| 1 In 1. 1. 1.   | 2 Scope  | <b>5</b> 5 5   |
| 2.<br>2.<br>2.<br>2.  | 2 Thermocouples  | 6<br>6<br>6<br>7<br>7  |
| 3 E<br>3.<br>3.   | 2 Sensor Board Layout Rev 1  | 8<br>8<br>9<br>13  |
| 4.<br>4.<br>4.<br>4.<br>4.<br>4.<br>4.<br>4.<br>4.<br>4.<br>4.<br>4.<br>4.<br>4 | 1 ID 0 - Clock Sync   2 ID 1 - Emergency Signal   3 ID 100 - Helium Pressure PT Data   4 ID 101 - LOX Pressure PT Data   5 ID 102 - Methane Pressure PT Data   6 ID 103 - Chamber Pressure PT Data   7 ID 200 - Helium Fill Valve Hall Effect State   8 ID 201 - LOX Fill Valve Hall Effect State   9 ID 202 - Methane Fill Valve Hall Effect State   10 ID 300 - Helium Tank Temperature Data   11 ID 301 - LOX Tank Temperature Data   12 ID 302 - Methane Tank Temperature Data   13 ID 303 - Nozzle Temperature Data   14 ID 304 - Upper Air Frame Temperature Data   15 ID 400 - Helium Pressure PT Current   16 ID 401 - LOX Pressure PT Current   17 ID 402 - Methane Pressure PT Current   18 ID 403 - Chamber Pressure PT Current   19 ID 404 - Helium Fill Valve Hall Effect Current   20 ID 405 - LOX Fill Valve Hall Effect Current   21 ID 406 - Methane Fill Valve Hall Effect Current | 14<br>14<br>14<br>14<br>14<br>14<br>15<br>15<br>15<br>15<br>15<br>16<br>16<br>16<br>16<br>16 |



# List of Tables



# List of Figures



## 1 Introduction

- 1.1 Purpose
- 1.2 Scope
- 1.3 Definitions and Acronyms



## 2 Hardware

## 2.1 Pressure Transducers

| Model Number         | MLH05KPSB01G              |
|----------------------|---------------------------|
| Serial Number        | F8CEA38AA5                |
| Usage                | Helium Pressure PT        |
| Datasheet Link       | Link                      |
| Sensing Units        | PSIG                      |
| Pressure Port Type   | 1/4-18 NPT (ANSI B1.20.1) |
| Accuracy             | $\pm 0.25\%$              |
| Pressure Range       | 0PSIG to 5000PSIG         |
| Sample Rate          | 50Hz                      |
| Output Voltage Range | 1.0 to 5.0 Volts          |
| Input Voltage Range  | 8.0 to 30.0 Volts         |
| Temperature Range    | -40°to +125°Celcius       |

| Model Number         | ASUHGP1K55A1AA1A20000             |
|----------------------|-----------------------------------|
| Serial Number        | E5C0ADEA35                        |
| Usage                | LOX Pressure PT                   |
| Datasheet Link       | Link                              |
| Sensing Units        | PSIG                              |
| Pressure Port Type   | 3/8 Inch 24 UNF Dash 3 (SAE J514) |
| Accuracy             | $\pm 0.25\%$                      |
| Pressure Range       | 0PSIG to 1500PSIG                 |
| Sample Rate          | 50Hz                              |
| Output Voltage Range | 0.5 to 4.5 Volts                  |
| Input Voltage Range  | 8.0 to 16.0 Volts                 |
| Temperature Range    | -40° to +150° Celcius             |

## 2.2 Thermocouples

| Model Number      | 240-080                     |
|-------------------|-----------------------------|
| Serial Number     | BB510C3CE3                  |
| Usage             | Upper Air Frame Temperature |
| Datasheet Link    | Link                        |
| Type              | K                           |
| Sensing Units     | Celcius                     |
| Sample Rate       | 10Hz                        |
| Temperature Range | -73°to +150°Celcius         |

| Model Number      | 240-080             |
|-------------------|---------------------|
| Serial Number     | BB51033CE3          |
| Usage             | Unused              |
| Datasheet Link    | Link                |
| Type              | K                   |
| Sensing Units     | Celcius             |
| Sample Rate       | 10Hz                |
| Temperature Range | -73°to +150°Celcius |



## 2.3 RTDs

| Model Number      | 1PT100K2515            |
|-------------------|------------------------|
| Serial Number     | 8105874731             |
| Usage             | LOX Tank Temperature   |
| Datasheet Link    | Link                   |
| Type              | PT100                  |
| Sensing Units     | Celcius                |
| Sample Rate       | 10Hz                   |
| Temperature Range | -200° to +150° Celcius |

## 2.4 Hall Effect Sensors

| Model Number        | TCS40DPR                   |
|---------------------|----------------------------|
| Serial Number       | 6D65BA9367                 |
| Usage               | LOX Fill Valve Hall Effect |
| Datasheet Link      | Link                       |
| Sensing Units       | mT                         |
| Output Type         | Push-Pull                  |
| Trip                | $\pm 4.4 \mathrm{mT}$      |
| Release             | $\pm 0.9 \mathrm{mT}$      |
| Input Voltage Range | 8.0 to 16.0 Volts          |
| Sample Rate         | 10Hz                       |
| Temperature Range   | -40° to +150° Celcius      |



# 3 EEPROM Layouts

## 3.1 Layout Version IDs

| VersionID | Version Name                    |
|-----------|---------------------------------|
| 1         | Sensor Board Layout Rev 1       |
| 2         | Power Distro Board Layout Rev 1 |



## 3.2 Sensor Board Layout Rev 1

| Byte # | Usage               | Byte # | Usage              | Byte #           | Usage               |
|--------|---------------------|--------|--------------------|------------------|---------------------|
| 0      |                     | 48     |                    | 96               |                     |
| 1      | Layout Rev Number   | 11     | 49 PT0 Calibration | 97               | PT1 Data CanID      |
| 2      |                     | 50     | Polyfit p1         | 98               | I II Bata Camb      |
| 3      |                     | 51     |                    | 99               |                     |
| 4      |                     | 52     |                    | 100              |                     |
| 5      | EEPROM Layout       | 53     | PT0 Calibration    | 101              | PT1 Current CanID   |
| 6      | Compile Time        | 54     | Polyfit p2         | 102              | 1 11 Current Camb   |
| 7      |                     | 55     |                    | 103              |                     |
| 8      |                     | 56     |                    | 104              |                     |
| 9      | Board Status        | 57     | PT0 Calibration    | 105              | PT1 Data Frequency  |
| 10     | Board Status        | 58     | Polyfit p3         | 106              | 1 11 Data Frequency |
| 11     |                     | 59     |                    | 107              |                     |
| 12     |                     | 60     |                    | 108              |                     |
| 13     | Board VIN Voltage   | 61     | PT0 Calibration    | 109              | PT1 Max Output      |
| 14     | CanID               | 62     | Polyfit p4         | 110              | Voltage             |
| 15     |                     | 63     |                    | 111              |                     |
| 16     |                     | 64     |                    | 112              |                     |
| 17     | Board current CanID | 65     | PT0 Calibration    | 113              | PT1 Min Output      |
| 18     | Board current Canib | 66     | Polyfit p5         | 114              | Voltage             |
| 19     |                     | 67     |                    | 115              |                     |
| 20     |                     | 68     |                    | 116              |                     |
| 21     | DEC D . G ID        | 69     | PT0 Calibration    | 117              | DELA D              |
| 22     | PT0 Data CanID      | 70     | Polyfit p6         | 118              | PT1 Max Pressure    |
| 23     |                     | 71     |                    | 119              |                     |
| 24     |                     | 72     |                    | 120              |                     |
| 25     | DEED G + G ID       | 73     | PT0 Calibration    | 121              | DEL M. D            |
| 26     | PT0 Current CanID   | 74     |                    | PT1 Min Pressure |                     |
| 27     |                     | 75     | _                  | 123              |                     |
| 28     |                     | 76     |                    | 124              |                     |
| 29     | DEC D . D           | 77     | PT0 Biguad Filter  | 125              | PT1 Calibration     |
| 30     | PT0 Data Frequency  | 78     | b0                 | 126              | Polyfit p1          |
| 31     |                     | 79     |                    | 127              |                     |
| 32     |                     | 80     |                    |                  |                     |
| 33     | DEED M. M. II       | 81     | PT0 Biquad Filter  |                  |                     |
| 34     | PT0 Max Voltage     | 82     | b1                 |                  |                     |
| 35     |                     | 83     |                    |                  |                     |
| 36     |                     | 84     |                    |                  |                     |
| 37     | DTO Min Voltage     | 85     | PT0 Biquad Filter  |                  |                     |
| 38     | PT0 Min Voltage     | 86     | b2                 |                  |                     |
| 39     |                     | 87     |                    |                  |                     |
| 40     |                     | 88     |                    | 1                |                     |
| 41     | PT0 Max Pressure    | 89     | PT0 Biquad Filter  |                  |                     |
| 42     | FIU Max Pressure    | 90     | a1                 |                  |                     |
| 43     |                     | 91     |                    |                  |                     |
| 44     |                     | 92     |                    |                  |                     |
| 45     | DEC M: D            | 93     | PT0 Biquad Filter  |                  |                     |
| 46     | PT0 Min Pressure    | 94     | a2                 |                  |                     |
|        |                     | 95     | ·                  | 1.1              | 1                   |



|                          |                               | Sensor Bo                | ard Layout Rev 1 Page #1      |                          |                                |
|--------------------------|-------------------------------|--------------------------|-------------------------------|--------------------------|--------------------------------|
| Byte #                   | Usage                         | Byte #                   | Usage                         | Byte #                   | Usage                          |
| 128<br>129<br>130<br>131 | PT1 Calibration<br>Polyfit p2 | 176<br>177<br>178<br>179 | PT2 Current CanID             | 224<br>225<br>226<br>227 | PT2 Calibration<br>Polyfit p7  |
| 132<br>133<br>134<br>135 | PT1 Calibration<br>Polyfit p3 | 180<br>181<br>182<br>183 | PT2 Data Frequency            | 228<br>229<br>230<br>231 | PT2 Biquad Filter<br>b0        |
| 136<br>137<br>138<br>139 | PT1 Calibration<br>Polyfit p4 | 184<br>185<br>186<br>187 | PT2 Max Voltage               | 232<br>233<br>234<br>235 | PT2 Biquad Filter<br>b1        |
| 140<br>141<br>142<br>143 | PT1 Calibration<br>Polyfit p5 | 188<br>189<br>190<br>191 | PT2 Min Voltage               | 236<br>237<br>238<br>239 | PT2 Biquad Filter<br>b2        |
| 144<br>145<br>146<br>147 | PT1 Calibration<br>Polyfit p6 | 192<br>193<br>194<br>195 | PT2 Max Pressure              | 240<br>241<br>242<br>243 | PT2 Biquad Filter<br>a1        |
| 148<br>149<br>150<br>151 | PT1 Calibration<br>Polyfit p7 | 196<br>197<br>198<br>199 | PT2 Min Pressure              | 244<br>245<br>246<br>247 | PT2 Biquad Filter<br>a2        |
| 152<br>153<br>154<br>155 | PT1 Biquad Filter<br>b0       | 200<br>201<br>202<br>203 | PT2 Calibration<br>Polyfit p1 | 248<br>249<br>250<br>251 | Hall Effect 0 Data<br>CanID    |
| 156<br>157<br>158<br>159 | PT1 Biquad Filter<br>b1       | 204<br>205<br>206<br>207 | PT2 Calibration<br>Polyfit p2 | 252<br>253<br>254<br>255 | Hall Effect 0<br>Current CanID |
| 160<br>161<br>162<br>163 | PT1 Biquad Filter<br>b2       | 208<br>209<br>210<br>211 | PT2 Calibration<br>Polyfit p3 |                          |                                |
| 164<br>165<br>166<br>167 | PT1 Biquad Filter<br>a1       | 212<br>213<br>214<br>215 | PT2 Calibration<br>Polyfit p4 |                          |                                |
| 168<br>169<br>170<br>171 | PT1 Biquad Filter<br>a2       | 216<br>217<br>218<br>219 | PT2 Calibration<br>Polyfit p5 |                          |                                |
| 172<br>173<br>174<br>175 | PT2 Data CanID                | 220<br>221<br>222<br>223 | PT2 Calibration<br>Polyfit p6 |                          |                                |



|                   |                    |                        | ard Layout Rev 1 Page #2 |        |                    |
|-------------------|--------------------|------------------------|--------------------------|--------|--------------------|
| Byte #            | Usage              | Byte #                 | Usage                    | Byte # | Usage              |
| 256               |                    | 304                    |                          | 352    |                    |
| 257               | Hall Effect 0 Data | 305                    | TC0 Biquad Filter        | 353    | RTD0 Biquad Filter |
| 258               | Frequency          | 306                    | a1                       | 354    | b1                 |
| 259               |                    | 307                    |                          | 355    |                    |
| 260               |                    | 308                    |                          | 356    |                    |
| 261               | Hall Effect 1 Data | 309                    | TC0 Biquad Filter        | 357    | RTD0 Biquad Filter |
| 262               | CanID              | 310                    | a2                       | 358    | b2                 |
| 263               | Camb               | 310                    | a2                       | 359    | 02                 |
| $\frac{263}{264}$ |                    | 312                    |                          | 360    |                    |
|                   | Hall Effect 1      | 11 -                   |                          |        | DED O D: 1 F:14    |
| 265               |                    | 313                    | TC1 Data CanID           | 361    | RTD0 Biquad Filter |
| 266               | Current CanID      | 314                    |                          | 362    | a1                 |
| 267               |                    | 315                    |                          | 363    |                    |
| 268               |                    | 316                    |                          | 364    |                    |
| 269               | Hall Effect 1 Data | 317                    | TC1 Data Frequency       | 365    | RTD0 Biquad Filter |
| 270               | Frequency          | 318                    | 1C1 Data Frequency       | 366    | a2                 |
| 271               |                    | 319                    |                          | 367    |                    |
| 272               |                    | 320                    |                          | 368    |                    |
| 273               | Hall Effect 2 Data | 321                    | TC1 Biquad Filter        | 369    |                    |
| 274               | CanID              | 322                    | b0                       | 370    | RTD1 Data CanID    |
| 275               |                    | 323                    |                          | 371    |                    |
| 276               |                    | 324                    |                          | 372    |                    |
| 277               | Hall Effect 2      | 325                    | TC1 Biquad Filter        | 373    | RTD1 Data          |
|                   | Current CanID      | 11                     | b1                       | 11     |                    |
| 278               | Current Canib      | 326                    | DI DI                    | 374    | Frequency          |
| 279               |                    | 327                    |                          | 375    |                    |
| 280               |                    | 328                    |                          | 376    |                    |
| 281               | Hall Effect 2 Data | 329                    | TC1 Biquad Filter        | 377    | RTD1 Biquad Filter |
| 282               | Frequency          | 330                    | b2                       | 378    | b0                 |
| 283               |                    | 331                    |                          | 379    |                    |
| 284               |                    | 332                    |                          | 380    |                    |
| 285               | TC0 D-+- CID       | 333                    | TC1 Biquad Filter        | 381    | RTD1 Biquad Filter |
| 286               | TC0 Data CanID 333 | 100 Data Camb   334 a1 | 382                      | b1     |                    |
| 287               |                    | 335                    |                          | 383    |                    |
| 288               |                    | 336                    |                          | 1      |                    |
| 289               |                    | 337                    | TC1 Biquad Filter        |        |                    |
| 290               | TC0 Data Frequency | 338                    | a2                       |        |                    |
| 291               |                    | 339                    | ~~                       |        |                    |
| 292               | 1                  | 340                    |                          | +      |                    |
| 292<br>293        | TC0 Biquad Filter  |                        |                          |        |                    |
| 293<br>294        | b0                 | 341                    | RTD0 Data CanID          |        |                    |
|                   | D0                 | 11 -                   |                          |        |                    |
| 295               |                    | 343                    |                          | 4      |                    |
| 296               |                    | 344                    | D                        |        |                    |
| 297               | TC0 Biquad Filter  | 345                    | RTD0 Data                |        |                    |
| 298               | b1                 | 346                    | Frequency                |        |                    |
| 299               |                    | 347                    |                          |        |                    |
| 300               |                    | 348                    |                          |        |                    |
| 301               | TC0 Biquad Filter  | 349                    | RTD0 Biquad Filter       |        |                    |
| 302               | b2                 | 350                    | b0                       |        |                    |
| 303               | 1                  | 351                    |                          | - 11   |                    |



|        |                    | Sensor Bo | ard Layout Rev 1 Pa | ge #3  |       |
|--------|--------------------|-----------|---------------------|--------|-------|
| Byte # | Usage              | Byte #    | Usage               | Byte # | Usage |
| 384    |                    | 432       |                     | 480    |       |
| 385    | RTD1 Biquad Filter | 433       |                     | 481    |       |
| 386    | b2                 | 434       |                     | 482    |       |
| 387    |                    | 435       |                     | 483    |       |
| 388    |                    | 436       |                     | 484    |       |
| 389    | RTD1 Biquad Filter | 437       |                     | 485    |       |
| 390    | a1                 | 438       |                     | 486    |       |
| 391    |                    | 439       | İ                   | 487    |       |
| 392    |                    | 440       |                     | 488    |       |
| 393    | RTD1 Biquad Filter | 441       |                     | 489    |       |
| 394    | a2                 | 442       | İ                   | 490    |       |
| 395    |                    | 443       |                     | 491    |       |
| 396    |                    | T 444     |                     | 492    |       |
| 397    |                    | 445       |                     | 493    |       |
| 398    |                    | 446       |                     | 494    |       |
| 399    |                    | 447       |                     | 495    |       |
| 400    |                    | 448       |                     | 496    |       |
| 401    |                    | 449       |                     | 497    |       |
| 402    |                    | 450       |                     | 498    |       |
| 403    |                    | 451       |                     | 499    |       |
| 404    |                    | 452       |                     | 500    |       |
| 405    |                    | 453       |                     | 501    |       |
| 406    |                    | 454       |                     | 502    |       |
| 407    |                    | 455       |                     | 503    |       |
| 408    |                    | 456       |                     | 504    |       |
| 409    |                    | 457       |                     | 505    |       |
| 410    |                    | 458       |                     | 506    |       |
| 411    |                    | 459       |                     | 507    |       |
| 412    |                    | 460       |                     | 508    |       |
| 413    |                    | 461       |                     | 509    |       |
| 414    |                    | 462       |                     | 510    |       |
| 415    |                    | 463       |                     | 511    |       |
| 416    |                    | 464       |                     | 011    |       |
| 417    |                    | 465       |                     |        |       |
| 418    |                    | 466       |                     |        |       |
| 419    |                    | 467       |                     |        |       |
| 420    |                    | 468       |                     |        |       |
| 421    |                    | 469       |                     |        |       |
| 422    |                    | 470       |                     |        |       |
| 423    |                    | 471       |                     |        |       |
| 424    |                    | 472       |                     |        |       |
| 425    |                    | 473       |                     |        |       |
| 426    |                    | 474       |                     |        |       |
| 427    |                    | 475       |                     |        |       |
| 427    |                    | 476       |                     |        |       |
| 428    |                    | 477       |                     |        |       |
| 430    |                    | 11        |                     |        |       |
| 430    |                    | 478       |                     |        |       |
| 431    |                    | 479       | 1                   | 11     |       |



## ${\bf 3.3} \quad {\bf Power~Distro~Board~Layout~Rev~1}$

|        |                  | Power Distro | Board Layout Rev | v 1 Page #0 |       |
|--------|------------------|--------------|------------------|-------------|-------|
| Byte # | Usage            | Byte #       | Usage            | Byte #      | Usage |
| 0      |                  | 48           |                  | 96          |       |
| 1      | Board Status     | 49           |                  | 97          |       |
| 2      | Board Status     | 50           |                  | 98          |       |
| 3      |                  | 51           |                  | 99          |       |
| 4      |                  | 52           |                  | 100         |       |
| 5      | Offboard Battery | 53           |                  | 101         |       |
| 6      | Voltage CANID    | 54           |                  | 102         |       |
| 7      |                  | 55           |                  | 103         |       |
| 8      |                  | 56           |                  | 104         |       |
| 9      | Offboard Battery | 57           |                  | 105         |       |
| 10     | Current CANID    | 58           |                  | 106         |       |
| 11     |                  | 59           |                  | 107         |       |
| 12     |                  | 60           |                  | 108         |       |
| 13     | Onboard Battery  | 61           |                  | 109         |       |
| 14     | Voltage CANID    | 62           |                  | 110         |       |
| 15     |                  | 63           |                  | 111         |       |
| 16     |                  | 64           |                  | 112         |       |
| 17     | Onboard Battery  | 65           |                  | 113         |       |
| 18     | Current CANID    | 66           |                  | 114         |       |
| 19     |                  | 67           |                  | 115         |       |
| 20     |                  | 68           |                  | 116         |       |
| 21     | Helix Loop CW    | 69           |                  | 117         |       |
| 22     | Voltage CANID    | 70           |                  | 118         |       |
| 23     |                  | 71           |                  | 119         |       |
| 24     |                  | 72           |                  | 120         |       |
| 25     | Helix Loop CW    | 73           |                  | 121         |       |
| 26     | Current CANID    | 74           |                  | 122         |       |
| 27     |                  | 75           |                  | 123         |       |
| 28     |                  | 76           |                  | 124         |       |
| 29     | Helix Loop CCW   | 77           |                  | 125         |       |
| 30     | Voltage CANID    | 78           |                  | 126         |       |
| 31     |                  | 79           |                  | 127         |       |
| 32     |                  | 80           |                  |             |       |
| 33     | Helix Loop CCW   | 81           |                  |             |       |
| 34     | Current CANID    | 82           |                  |             |       |
| 35     |                  | 83           |                  |             |       |
| 36     |                  | 84           |                  |             |       |
| 37     |                  | 85           |                  |             |       |
| 38     |                  | 86           |                  |             |       |
| 39     |                  | 87           |                  |             |       |
| 40     |                  | 88           |                  |             |       |
| 41     |                  | 89           |                  |             |       |
| 42     |                  | 90           |                  |             |       |
| 43     |                  | 91           |                  |             |       |
| 44     |                  | 92           |                  |             |       |
| 45     |                  | 93           |                  |             |       |
| 46     |                  | 94           |                  |             |       |
| 47     |                  | 95           |                  |             |       |



## 4 CAN IDs

#### 4.1 ID 0 - Clock Sync

Frequency: 50Hz

| Byte | Bit | Signed | Range           | Units        | Description |
|------|-----|--------|-----------------|--------------|-------------|
| 0-3  |     | False  | 0 to 4294967295 | Milliseconds | UTC time    |

### 4.2 ID 1 - Emergency Signal

Frequency: 50Hz

| Byte | Bit | Signed | Range | Units | Description   |
|------|-----|--------|-------|-------|---------------|
| 0    |     | False  |       |       | Status        |
|      | 0-1 |        |       |       | System Status |

#### 4.3 ID 100 - Helium Pressure PT Data

Frequency: 50Hz

| Byte | Bit | Signed | Range | Units        | Description     |
|------|-----|--------|-------|--------------|-----------------|
| 0-3  |     | False  |       | Milliseconds | UTC time        |
| 4-5  |     | False  |       | PSIG         | Helium Pressure |

#### 4.4 ID 101 - LOX Pressure PT Data

Frequency: 50Hz

| Byte | Bit | Signed | Range | Units        | Description  |
|------|-----|--------|-------|--------------|--------------|
| 0-3  |     | False  |       | Milliseconds | UTC time     |
| 4-5  |     | False  |       | PSIG         | LOX Pressure |

#### 4.5 ID 102 - Methane Pressure PT Data

Frequency: 50Hz

| Byte | Bit | Signed | Range | Units        | Description      |
|------|-----|--------|-------|--------------|------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time         |
| 4-5  |     | False  |       | PSIG         | Methane Pressure |

#### 4.6 ID 103 - Chamber Pressure PT Data

Frequency: 50Hz

| Byte | Bit | Signed | Range | Units        | Description      |
|------|-----|--------|-------|--------------|------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time         |
| 4-5  |     | False  |       | PSIG         | Chamber Pressure |

#### 4.7 ID 200 - Helium Fill Valve Hall Effect State

Frequency:  $10 \mathrm{Hz}$ 

| Byte | Bit | Signed | Range | Units        | Description                   |
|------|-----|--------|-------|--------------|-------------------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time                      |
| 4    |     | False  |       | Open/Closed  | Helium Fill Valve Hall Effect |
|      |     |        |       |              | State                         |



#### 4.8 ID 201 - LOX Fill Valve Hall Effect State

Frequency: 10Hz

| Byte | Bit | Signed | Range | Units        | Description                      |
|------|-----|--------|-------|--------------|----------------------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time                         |
| 4    |     | False  |       | Open/Closed  | LOX Fill Valve Hall Effect State |

#### 4.9 ID 202 - Methane Fill Valve Hall Effect State

Frequency: 10Hz

| Byte | Bit | Signed | Range | Units        | Description                    |
|------|-----|--------|-------|--------------|--------------------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time                       |
| 4    |     | False  |       | Open/Closed  | Methane Fill Valve Hall Effect |
|      |     |        |       |              | State                          |

#### 4.10 ID 300 - Helium Tank Temperature Data

Frequency: 10Hz

|      | v   |        |       |              |                         |
|------|-----|--------|-------|--------------|-------------------------|
| Byte | Bit | Signed | Range | Units        | Description             |
| 0-3  |     | False  |       | Milliseconds | UTC time                |
| 4-5  |     | True   |       | Celcius      | Helium Tank Temperature |

#### 4.11 ID 301 - LOX Tank Temperature Data

Frequency: 10Hz

|   | 1    | -,  | _      |       |              |                      |
|---|------|-----|--------|-------|--------------|----------------------|
|   | Byte | Bit | Signed | Range | Units        | Description          |
| ĺ | 0-3  |     | False  |       | Milliseconds | UTC time             |
| ĺ | 4-5  |     | True   |       | Celcius      | LOX Tank Temperature |

#### 4.12 ID 302 - Methane Tank Temperature Data

Frequency: 10Hz

| Byte | Bit | Signed | Range | Units        | Description              |
|------|-----|--------|-------|--------------|--------------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time                 |
| 4-5  |     | True   |       | Celcius      | Methane Tank Temperature |

#### 4.13 ID 303 - Nozzle Temperature Data

Frequency: 10Hz

| Byte | Bit | Signed | Range | Units        | Description        |
|------|-----|--------|-------|--------------|--------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time           |
| 4-5  |     | True   |       | Celcius      | Nozzle Temperature |

#### 4.14 ID 304 - Upper Air Frame Temperature Data

Frequency: 10Hz

| Byte | Bit | Signed | Range | Units        | Description                 |
|------|-----|--------|-------|--------------|-----------------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time                    |
| 4-5  |     | True   |       | Celcius      | Upper Air Frame Temperature |

#### 4.15 ID 400 - Helium Pressure PT Current

Frequency: 10Hz

| E | Byte | Bit | Signed | Range | Units        | Description                |
|---|------|-----|--------|-------|--------------|----------------------------|
| 0 | -3   |     | False  |       | Milliseconds | UTC time                   |
| 4 | -5   |     | True   |       | milliamps    | Helium Pressure PT Current |



#### 4.16 ID 401 - LOX Pressure PT Current

Frequency: 10Hz

| Byte | Bit | Signed | Range | Units        | Description             |
|------|-----|--------|-------|--------------|-------------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time                |
| 4-5  |     | True   |       | milliamps    | LOX Pressure PT Current |

#### 4.17 ID 402 - Methane Pressure PT Current

Frequency: 10Hz

|   | Byte | Bit | Signed | Range | Units        | Description                 |
|---|------|-----|--------|-------|--------------|-----------------------------|
| Ì | 0-3  |     | False  |       | Milliseconds | UTC time                    |
| Ī | 4-5  |     | True   |       | milliamps    | Methane Pressure PT Current |

#### 4.18 ID 403 - Chamber Pressure PT Current

Frequency: 10Hz

| Byte | Bit | Signed | Range | Units        | Description                 |
|------|-----|--------|-------|--------------|-----------------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time                    |
| 4-5  |     | True   |       | milliamps    | Chamber Pressure PT Current |

#### 4.19 ID 404 - Helium Fill Valve Hall Effect Current

Frequency: 10Hz

| Byte | Bit | Signed | Range | Units        | Description                   |
|------|-----|--------|-------|--------------|-------------------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time                      |
| 4-5  |     | True   |       | milliamps    | Helium Fill Valve Hall Effect |
|      |     |        |       |              | Current                       |

#### 4.20 ID 405 - LOX Fill Valve Hall Effect Current

Frequency: 10Hz

| Byte | Bit | Signed | Range | Units        | Description                     |
|------|-----|--------|-------|--------------|---------------------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time                        |
| 4-5  |     | True   |       | milliamps    | LOX Fill Valve Hall Effect Cur- |
|      |     |        |       |              | rent                            |

#### 4.21 ID 406 - Methane Fill Valve Hall Effect Current

Frequency: 10Hz

| Byte | Bit | Signed | Range | Units        | Description                    |
|------|-----|--------|-------|--------------|--------------------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time                       |
| 4-5  |     | True   |       | milliamps    | Methane Fill Valve Hall Effect |
|      |     |        |       |              | Current                        |

### 4.22 ID 407 - Upper Air Frame VIN Current

Frequency: 10Hz

| Byte | Bit | Signed | Range | Units        | Description                   |
|------|-----|--------|-------|--------------|-------------------------------|
| 0-3  |     | False  |       | Milliseconds | UTC time                      |
| 4-5  |     | True   |       | Milliamps    | Upper Air Frame Board Current |



# 4.23~ ID 500 - Upper Air Frame VIN Voltage

Frequency: 10Hz

| 1    |     |        |       |              |                           |  |
|------|-----|--------|-------|--------------|---------------------------|--|
| Byte | Bit | Signed | Range | Units        | Description               |  |
| 0-3  |     | False  |       | Milliseconds | UTC time                  |  |
| 4-5  |     | True   |       | Millivolts   | Upper Air Frame Board VIN |  |
|      |     |        |       |              | Voltage                   |  |